

Oxford Instruments glass X-ray tubes are recognized for their performance and long life.

High flux and spot size stability make our X-ray tubes an ideal solution for demanding applications, such as those requiring continuous operation. The 90507 and other 1000 series tubes are uniquely designed with a very small isostatically focused spot for high resolution applications, such as mini C-Arm fluoroscopy. The robust electron gun assembly has been constructed for optimal use in integrated X-ray sources, where heat dissipation is an issue. Long tube life is achieved by ultra-high vacuum maintained with the Oxford Instruments unique Pin Flash getter. This tube operates in bi-polar mode.



Benefits

- Exceptional image quality
- Stable X-ray output delivers high precision measurements
- Small, stable spot delivers distortion-free measurements
- RoHS compliant design

Applications

- CT imaging for life sciences and industrial inspection
- Densitometry
- Thickness gauging
- Phase contrast imaging
- Medical imaging


Specifications	
Operating voltage range:	90507, 90501: 40-80kV (bi-polar operation: -40kV cathode, +40kV anode) 90502: 40 - 65kV
Maximum Power:	See product ordering table.
Maximum beam current:	See product ordering table.
Maximum filament current:	1.7A
Filament voltage:	2.0V (nominal)
Focus to Object Distance (FOD):	14.2mm (0.56") (nominal)
Window material and thickness:	Glass—1.40mm ± 0.15
Target material:	W
Target angle:	20°
Maximum oil temperature:	80°C
Cooling method:	Oil
Weight:	114g (0.25 lbs)
Storage conditions:	-10°C to 55°C Barometric Pressure: 50-106kPa; Humidity: 10-90% (no condensation)



The Business of Science®



1000 Series - Glass X-ray Tube



Notes

1. Dimensions are in inches.
2. This X-ray tube is designed to operate in an oil filled high voltage enclosure. Do not allow the oil to exceed 80°C. Proper operation of the X-ray tube requires cooling oil to circulate freely around the X-ray tube envelope.
3. This X-ray tube produces X-rays in all directions. As such, it must only be operated in a radiation-shielded enclosure.
4. Tubes to be shipped with two teflon-coated copper wire leads, 18 AWG X 12.0 MIN, soldered to pins #6 and #2.

Product Ordering Table

Part Number	Outline Drawing	Target	Operating Range (kV)	Max Anode Current (mA)	Max Anode Power (W)	Max Filament Current (A)	Spot Size (µm)**
90501	8218	W	40 - 80	0.7	56	1.7	100 Max.
90502	8218	W	40 - 65	0.5	32.5	1.7	90 Max.
90507	8218	W	40 - 80	0.5	40	1.7	33 Nom.

Note: Part number specific copies of outline drawings and product specification sheets are available.
 **Max. = Maximum, Typ. = Typical, Nom. = Nominal (per IEC60336, NEMA XR5-1999)

Visit xray.oxinst.com or xray-sales@oxinst.com for more information.

This publication is the copyright of Oxford Instruments plc and provides outline information only, which (unless agreed by the company in writing) may not be used, applied or reproduced for any purpose or form part of any order or contract or regarded as the representation relating to the products or services concerned. Oxford Instruments' policy is one of continued improvement. The company reserves the right to alter, without notice the specification, design or conditions of supply of any product or service. Oxford Instruments acknowledges all trademarks and registrations.
 © Oxford Instruments plc, 2019. All rights reserved. Document reference: Part no: DS065 - November 5, 2019



The Business of Science®



X-ray Technology
 360 El Pueblo Road
 Scotts Valley, CA 95066, USA

Phone: +1 (831) 439-9729
 Fax: +1 (831) 439-6050
 Email: xray-sales@oxinst.com